

# Sensor Unit CTB104 CTB104A



Shenzhen Zhiyong Electronics Co., LTd

www.cybertek.cn



# Preface

First of all, thank you for purchasing our products, this instruction manual is the description about the function, usage, operation attention points, etc. Before use, please read the instructions carefully and use correctly.

Manual annotation will use the following symbols to distinguish.



This symbol means it is harmful to the machine and human body; you must strictly follow the instruction manual to operate.



In the case of wrong operation, the user risk injury. The content under this mark records the relevant matters needing attention to avoid such dangers.

Warning

The user may suffer minor injuries and material damage with the wrong operation. To avoid such situation, the matters under this mark need attention.



This symbolizes important note about how to use the machine.



This product is the power supply designed for our CTBxxxA series high accuracy current transducer, so we require users to:

- Do not try to connect cables or open the shell during operation. Do not use the device in damp or combustible environment. Make sure the surface of the device is dry and clean before usage.
- Make sure the product is used in rated voltage and current range.
- If there's anything wrong with our product, please contact us immediately. Do not open the shell and try to repair on your own to avoid accident.



#### 1.Summary

**CTB104/A** is the sensor unit designed for the CTBxxxA series high accuracy current transducer. Connecting with each other through the specialized 8pin connector, CTB104/A sensor unit can connect with 4 pcs CTBxxxA series product at the same time. With auto-zero and degaussing function and sensor signal output connector, CTB104/A can realize the degaussing and zero setting to corresponding channel through the button on panel. CTB104/A has standard BNC signal output connector, able to connect with the devices like oscilloscope or power analyzer, of any brand

#### **2.Product description**



① Power indicator light: indicating power supply ON with green light.

② Degaussing zero set button: realizing the zero setting and degaussing of the current probe of corresponding channel.

③ Signal output: the signal output to the corresponding channel through standard BNC connector and connect with devices like power analyzer or oscilloscope.

④ Sensor connector: Connecting CTBxxxA series sensor with the sensor unit, realizing connection between sensor and sensor unit.

Model	CTB104		CTB104A
Suitable current Sensor	СТВ20А, СТВ200А, СТВ501А,		CTB2000A
	CTB500A, CTB1000A		CIB2000A
Zero set and degaussing	4 channel independent control		
Signal output connector	BNC(4 channel independent output)		
Output voltage range	$\pm 12 \pm 0.5 V$		$\pm 14.7V\pm\!\!0.5V$
Output current range	0.6Amax (per channel)		
Input Voltage Range	90~264VAC		
Frequency	47~63Hz		
Operating environment humidity	20~70%RH no condensation		
Operating environment temperature	-20~+70°C		
Storage temperature and humidity	-40~+85°C、10~95%		
Dimension(L*W*H)	215*110mm*160mm		
Weight	1.5kg		

## **3.**Electronics Specification



## 4.Operating Method

- ♦ Connect the CTB104/A sensor unit with the CTBxxxA series current transducer.
- Connect the output connector of the sensor unit with terminal device such as oscilloscope or power analyzer through BNC cable.
- ✤ Turn on CTB104/A sensor unit.
- $\diamond$  Executing zero set and degaussing through the button on probe or sensor unit.
- $\diamond$  Unlocking the jaw with push-rod .
- $\diamond$  Using the rod to open/close the jaw.
- Clip in the cable under test according to current direction and close the jaw. (Signal will be reversed if the direction is wrong.)
- ♦ Close the jaw with locking push-rod.
- $\diamond$  Start testing.
- ♦ Unplug the device after testing finished.
- $\diamond$  Cut off the power on sensor unit.

#### **5.Packing List**

Packing List			
Name	Amount		
Sensor unit	1		
BNC output cable CK-310	4		
AC power supply cable	1		
Instruction manual	1		
Warranty card	1		

# **CYBERTEK**

#### SHENZHEN ZHIYONG ELECTRONICS CO., LTD.

Addr: Room A1702, Building 4, TianAn Cyber Park, HuangGe Road, LongGang

District, ShenZhen City, China

**Tel:** (86) 400 852 0005 / (86 755) 86628000

**Q Q:** 400 852 0005

Email: cybertek@cybertek.cn

Url: http://www.cybertek.cn

© Zhiyong Electronics, 2025 Published in China, Jul. 1, 2025